


# MRP

SUPPORTS

# 18X36 METAL SAFETY BACKER TRAY

HEAVY DUTY  
GALVANIZED  
STEEL TRAY



TRAY SIZE: 18" X 36"

3M 550 ADHESIVE SEALANT

TRAY IS SMALLER THAN TILE

## PAVER TRAY INSTRUCTIONS

- STEP 1:** Have material prepped & set in front of you
- STEP 2:** Load gun with adhesive, cut tip of applicator 1/4" at angle & secure tube
- STEP 3:** Start first bead 1/2" from edge of tile. Continue process laying beads 2"-3" apart until reaching other side. **Note:** Last bead may be less than 3" from edge of tile, bead lines to be minimum 1/4" wide
- STEP 4:** Place tray over adhesive & center on paver. **Note:** Tray is smaller than the porcelain tile
- STEP 5:** Press tray onto paver firmly to ensure proper adhesion
- STEP 6:** Allow pavers & trays to set up for a minimum of 24 hours before installing on pedestals
- STEP 7:** Adhesive sets in 24 hours, can take up to 7 days to fully cure
- STEP 8:** Each paver will take about 1/4 of a tube of adhesive